

USER'S MANUAL Controller (Network Adaptor) Model No. CZ-TACG1



Controller (Network Adaptor) Model No. CZ-TACG1

Table of Contents

System Overview.4Before Installing the Adaptor .4Parts Identification4Parts.5Adaptor Installation5Connecting Network.6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	Safety Precautions	.2 ~ 3
Before Installing the Adaptor4Parts Identification4Parts5Adaptor Installation5Connecting Network6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	System Overview	4
Parts Identification4Parts5Adaptor Installation5Connecting Network6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	Before Installing the Adaptor	4
Parts5Adaptor Installation5Connecting Network6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	Parts Identification	4
Adaptor Installation5Connecting Network6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	Parts	5
Connecting Network6Starting "Panasonic Comfort Cloud"6Use the "Panasonic Comfort Cloud"9Troubleshooting14Information15Firmware Update Function15Software License Information16	Adaptor Installation	5
Starting "Panasonic Comfort Cloud"	Connecting Network	6
Use the "Panasonic Comfort Cloud"	Starting "Panasonic Comfort Cloud"	6
Troubleshooting14Information15Firmware Update Function15Software License Information16	Use the "Panasonic Comfort Cloud"	9
Information	Troubleshooting	14
Firmware Update Function15 Software License Information16	Information	15
Software License Information16	Firmware Update Function	15
	Software License Information	16



Thank you for purchasing this Panasonic product.

Please read these instructions carefully before using this product, and save this manual for future use.

Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation.
- Electrical work must be installed by a licensed electrician. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.
- Please provide this setup guide to the user after installation. Instruct user to keep it with the instruction manuals of the air conditioner in safe location.



The items to be followed are classified by the symbols:

S F

Ţ

Symbol with white background denotes item that is PROHIBITED from doing.

Symbol with dark background denotes item that must be carried out.





- This can cause electric shock or ignition due to shorting.
- Do not disassemble or modify.
 - This can cause electric shock or ignition.

- Do not touch with wet hands.
 - This can cause electric shock or ignition due to shorting.
- Do not set up in hospitals or places where electronic medical devices are located.
 - Radio waves emitting from this adaptor may interfere with electronic medical devices and cause them to malfunction.
- Do not set up where children can reach the adaptor.
 - They may pull on it or cause themselves an injury.
- Do not wipe with wet cloths or wash in water.
 - This can cause electric shock or ignition.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
 - Request installation only from the place of purchase or an installer.
 - Not doing so may cause electric shock or ignition.
 - Shut off the power supply when installing this adaptor.
 - Not doing so may cause electric shock.
 - Use only the specified parts when installing the adaptor and perform the installation correctly by following the instructions.
 - Not doing so may cause electric shock or ignition.

- Ensure cables are installed properly so that external forces cannot affect them.
 - Not doing so may cause overheating which can lead to ignition.
- Stop use as soon as you notice any problems or malfunctions and shut off the electric supply to the connected appliance.
 - Not doing so may cause smoke, ignition, electric shock, or burns.
 - Examples of problems and malfunctions
 - There is a burning smell
 - Water or a foreign object has gotten inside
 - → Immediately request repair from the place of purchase or the installer.

- The adaptor is indoor use only. Do not set up outside or in unsecured locations.
 - It may provide an entry point for unauthorised network access.
- Do not set up in locations exposed to direct sunlight, where the temperature may exceed 45°C or go below -5°C.
 - This can cause deformation.
- Do not install in locations where oils are used a lot or where steam or sulphurous gases are emitted.
 - This can cause loss of performance or deformation.

• Before connecting wires and cables, discharge any static electricity.

- Not doing so may cause malfunction.

System Overview

• Do not stand on an unstable surface when operating or checking the adaptor.

- This can cause injury from falls.



Before Installing the Adaptor

- Requires a Smartphone that is iOS/Android compatible;
- The Network adaptor (adaptor) is designed specifically as a terminal for the "Panasonic Comfort Cloud";
- Do not attach the adaptor to metal as wireless performance will be adversely affected;
- The adaptor recommended to be installed outside of the indoor unit. (It needs to be accessed when connecting it or when there is a problem.);
- The Wireless LAN network coverage must include the air conditioner installation location;
- Do connect the Wireless LAN to a compatible Panasonic Air Conditioner with a connectivity interface port.

Specification

•	
Input Voltage	DC 12V (From air conditioner indoor unit)
Power consumption	Max: 660 mW
Size	66 mm (H) x 36 mm (W) x 12 mm (D)
Weight	Approx. 85g
Interface	1x Wireless LAN
Wireless LAN standard	IEEE 802.11 b/g/n
Frequency range	2.4 GHz band
Encryption	WPA2-PSK (TKIP/AES)

Parts Identification





No	Item	Description		
1	Power LED	Indicates that the adaptor is being supplied with power.		
2	Link LED	Indicate the communication status of adaptor to the server.		
3	Status LED	Indicate the communication status of adaptor to the air-conditional. Green: status without weekly timer Orange: status with weekly timer Red: Abnormality Red \rightarrow Orange \rightarrow Green : Auto updating \uparrow adaptor firmware During signal strength checking:- Strong: $\bigcirc \bigcirc \bigcirc$		
4	Setup Switch*	Connection setup mode switching		
5	Check Switch*	Signal strength checking (press and hold for 5 seconds then release) Disable LEDs display (press and hold for 10 seconds then release)		
6	Reset*	Soft reset		

* The device factory reset can be done by press and hold CHECK and SETUP button for 10 seconds. After release the CHECK and SETUP button, press the reset button.

Parts

Adaptor Unit (CZ-TACG1)	
Screw for mounting (M4 x 20 – 1 piece)	(Jamas
Mounting cord clamp (1 piece)	
Cable tie (1 piece)	
Double-sided adhesive tape	
Wall plug	Treas

Adaptor Installation

1. Attach the Adaptor unit with double-sided adhesive tape on the wall near the indoor unit.

- Shut off the power supply when installing this adaptor.

- Make sure the wall is clean and free from dirt.



2. Use the cord clamp to fix the cable to the wall.

Pull the cable around as shown in the diagram so that the external force cannot act on the connector in the adaptor. Furthermore, on the indoor unit end, use the included cable tie to fix the cables together when necessary.



3. Connect the cable to the CN-CNT connector at the indoor unit.

Take note each indoor unit CN-CNT connector location might be different. Please consult authorized dealer.

Connecting Network

Establish network connection to the internet via Wireless mode.

1. Turn on the power supply to the indoor unit.

- The Power LED lights (green).
- The Status LED blinking (green).



2. Download and install the "Panasonic Comfort Cloud".





Follow the instruction of the app to complete the installation setup. Refer to next page.
All LEDs lights (green).



Starting "Panasonic Comfort Cloud"

Use a Smartphone that is iOS/Android compatible.

- User interface image may change without notification.
- There is no charge for using this application. However, other charges may be incurred for connection and operation.
- Updates to the service may mean there are changes to the design of the screen and display.

1. Login to the "Panasonic Comfort Cloud"

Login
Please enter your Panasonic ID and password.
Panasonic ID
Panasonic ID
Password
Password
Remember me
Forgot ID/Password
Create new Panasonic ID
View an example
Login

Login with your Panasonic ID and password. Panasonic ID can be registered free from the link on the page or at the following URL.

(https://csapl.pcpf.panasonic.com/Account/Register 001)

2. Connection Guide



- i. At My Home screen, tap "+" to add new product.
- ii. Select the product that you want to add.
- iii. Tap "Start" to begin the connection setup.



iv. Tap "Next" after confirming the POWER LED of the network adaptor is ON.

v. If you are the first user (administrator) to operate the air conditioner via this application, reset the network adaptor with a pin and tap "Next".



Connection Guide

3.1 Connect with WPS Mode

- i. Press the "WPS" button on the router to establish connection.
- ii. Tap "Next" after the router is ready for connection.
- iii. Press and hold the "SETUP" button on the network adaptor for 5 seconds.
- iv. Release the "SETUP" button when both STATUS LED and LINK LED start to blink. Tap "NEXT".



The router supports WPS

Cancel

vi. Choose the button that matches the status of LINK LED on the network adaptor.

- Connection Guide Step 2 Step 3 Connect with WPS mode The router does not support WPS. Connect with AP mode
 - vii. Tap on the preferred connection setup mode. - To "Connect with WPS mode", proceed to instruction 3.1 (For router that supports WPS) - To "Connect with AP mode", proceed to instruction
 - 3.2 (For router that does not support WPS)

- Step 2 Step 3 The LINK LED will light up when the network fully connects to the serve Tap "Next" after the LINK LED is ON Next Tap "Check" for the following cases. -LINK LED continues blinking -STATUS LED is red Check Cancel
- Wait until LINK LED is ON indicates the connection v. setup is complete. Tap "NEXT" and proceed to instruction 4.

3.2 Connect with AP Mode



i. Press and hold the "SETUP" button on the network adaptor for 10 seconds.

Release the "SETUP" button when the STATUS LED ii. starts to blink in orange.

iii. Tap "NEXT".



iv. Tap "To wireless network settings of the smartphone" to change the wireless network connection of the smartphone to the following network, the smartphone will connect to the network adaptor.

A window will prompt, tap "Copy password and next"

to proceed to smartphone wireless network setting.

vi. Connect to "Panasonic-CZ-T-wirelessAP" network

and back to the application to continue with the

SSID: Panasonic-CZ-T-wirelessAP Password: Rac8pswa



V.

setup.

Copy password and next

Return to this application after completing the wireless network settings to continue the setup.

Connection Guide Step 2 Step 3 Next, setup the wireless network connection of the network adaptor. To wireless network setting Cancel

< Co	nnection G	uide	=
Step 1	Step 2	Step	3
Connect the netw wireless router. Select your wirel	work adaptor t ess router.	o the	
ASUS_EU		4	P 🔒
TM_A20A		4	
Other			
MAC address of t 3c-95-09-07-ca	arget device -84		
Note: Select 2.4 GHz ba supports both 2.	ind if the wirel 4 GHz and 5 Gł	ess router Hz band.	
	Cancel		

viii. Connect the network adaptor to wireless router.

vii. Tap "To wireless network setting" to setup the

wireless network connection of the network

Select your wireless router.

adaptor.

ix. Enter the password of the selected wireless router.



x. The LINK LED will light up when the network adaptor successfully connects to the server. Tap "NEXT" and proceed to instruction 4. *During network adaptor connecting to wireless router, STATUS LED and LINK LED will blink simultaneously.

Cancel (go back to previous screen)

4. Setup completion

i.



- Input the Device ID. Device ID is written at name plate attached to the network adaptor or label attached on the packaging.
- ii. Set the password for the network adaptor.
- iii. Tap "Register" to complete the setup.



iv. You can name the air conditioner unit to help you identify it.

Use the "Panasonic Comfort Cloud"



User's manual can be found under Menu tab.

The "Panasonic Comfort Cloud" is connected to the network adaptor and ready for use.

Login

Install and launch the app



"Panasonic Comfort Cloud" (Android 4.4 and above)



"Panasonic Comfort Cloud" (iOS 9 and above)

Login Page



Home Screen



Main Menu



User list



Change of device password



Replace the device



Select "Replace device" from the menu

Tap Start

Follow the step by step instruction from



Change the router setting



Select "Change router setting" from the menu

Tap Start

Follow the step by step instruction from app



Device list



Group List



Main Device Screen



Information



Air Conditioner Status



Advance setting



Operating mode



-Additional features off / on

Statistics



* Estimated energy consumption may not be supported by certain models.

Comparison



	<	J	an.201	8	>	
М	т	W	т	F	S	S
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

Date selection



Month selection



Week selection



Year selection

Weekly Timer





Add new timer



ОК

Troubleshooting

- When the power LED does not light up (no power supply to the adaptor)
 - \rightarrow Check the power supply.
 - \rightarrow Check the connection of the cable.
- When the status LED does not light up (Adaptor can't communicate with air-conditioner)
 - \rightarrow Check the connection of the cable.
- The connection between your device and a client through wireless network cannot be established.
 - \rightarrow Ensure that the wireless network function is enabled.
 - \rightarrow Refresh the network list and select the correct SSID.
 - $\rightarrow\,$ Check the IP address, and ensure that your client can automatically obtain an IP address.
 - $\rightarrow\,$ Enter the correct network key (wireless network password) when you connect with AP mode.
- Reset device Password
 - (In case you forgot the device Password)
 - \rightarrow Remove the device from device list and add back the device.
 - → Factory reset the device and add back the device. The device factory reset can be done by press and hold CHECK and SETUP button for 10 seconds. After release the CHECK and SETUP button, press the reset button.



Information

English

Information for Users on Collection and Disposal of Old Equipment

- - Your product is marked with this symbol. This symbol means that electrical and electronic products shall not be mixed with unsorted household waste.



- Do not try to dismantle the system yourself: the dismantling of the product and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.
- Product and waste must be treated at a specialized treatment facility for re-use, recycling and recovery.

These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

For users in the European Union

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

[Information on Disposal in other Countries outside the European Union] These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Declaration of Conformity (DOC)

Hereby, "Panasonic Corporation" declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU The full text of the EU declaration of conformity is available at the following internet address: http://www.ptc.panasonic.eu/ Authorized Representative: Panasonic Testing Centre, Panasonic Marketing Europe GmbH, Winsbergring 15, 22525 Hamburg, Germany Norway: There are usage restrictions within a radius of 20 km from the centre of Ny-Alesund on Svalbard.

Firmware Update Function

This product has functionality for connecting to the Panasonic firmware update server over the Internet to automatically update the device firmware to the latest version.

To update the firmware, the device will do check, once per day, whether its firmware is the latest version after power up. And if an update is required, the update is applied and the device restarts automatically. Operations are not possible while the device is being restarted (which takes about 1-5 minutes).

Software License Information

This product incorporates the following software:

- (1) The software developed independently by or for Panasonic Corporation,
- (2) The software owned by third party and licensed to Panasonic Corporation,
- (3) The open source software under the BSD licence and/or equivalent licenses.

The software categorized as of (3) is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY, without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

The following license terms shall be applied to Open-Sourced Components.

1. Supplicant license

Copyright (C) 2003-2016, Jouni Malinen $<\!\!j@w1.fi\!\!>$ and contributors. All rights reserved.

This software may be distributed, used, and modified under the terms of BSD license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. Neither the name(s) of the above-listed copyright holder(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS AS IS AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Setting Information

Wireless interface address (MAC)	
Wireless interface serial number (ID)	
Wireless interface code (PIN)	
Indoor unit model name	
Indoor unit serial number	
Outdoor unit model name	
Outdoor unit serial number	
System commissioning date	
Wireless interface installation date	

Installer Contact Details

Name	
Telephone number	

Maximum radio-frequency power transmitted in the frequency bands

Type of wireless	Frequency band	Max EIRP (dBm)
WLAN	2412-2472 MHz	20 dBm

Manufactured by:	Panasonic Corporation
	1006 Kadoma, Kadoma City, Osaka, Japan
Importer for Europe:	Panasonic Marketing Europe GmbH
	Panasonic Testing Centre
	Winsbergring 15, 22525 Hamburg, Germany