

1 SELECT THE BEST LOCATION (Refer to "Select the best location" section)

2 HOW TO FIX INSTALLATION PLATE

The mounting wall shall be strong and solid enough to prevent it from vibration.

Dimension					
①	②	③	④	⑤	⑥
465 mm	70 mm (+)	365 mm	415 mm	10 mm	70 mm

- The center of installation plate should be at more than ① at right and left of the wall.
- The distance from installation plate edge to ceiling should more than ②.
- From installation plate center to unit's left side is ③.
- From installation plate center to unit's right side is ④.

⑤ For left side piping, piping connection for liquid should be about ⑤ from this line.

⑥ For left side piping, piping connection for gas should be about ⑥ from this line.

⑦ For left side piping, piping connection for gas should be about ⑥ from this line.

⑧ For left side piping, piping connection for gas should be about ⑥ from this line.

⑨ For left side piping, piping connection for gas should be about ⑥ from this line.

⑩ For left side piping, piping connection for gas should be about ⑥ from this line.

⑪ For left side piping, piping connection for gas should be about ⑥ from this line.

⑫ For left side piping, piping connection for gas should be about ⑥ from this line.

⑬ For left side piping, piping connection for gas should be about ⑥ from this line.

⑭ For left side piping, piping connection for gas should be about ⑥ from this line.

⑮ For left side piping, piping connection for gas should be about ⑥ from this line.

⑯ For left side piping, piping connection for gas should be about ⑥ from this line.

⑰ For left side piping, piping connection for gas should be about ⑥ from this line.

⑱ For left side piping, piping connection for gas should be about ⑥ from this line.

⑲ For left side piping, piping connection for gas should be about ⑥ from this line.

⑳ For left side piping, piping connection for gas should be about ⑥ from this line.

㉑ For left side piping, piping connection for gas should be about ⑥ from this line.

㉒ For left side piping, piping connection for gas should be about ⑥ from this line.

㉓ For left side piping, piping connection for gas should be about ⑥ from this line.

㉔ For left side piping, piping connection for gas should be about ⑥ from this line.

㉕ For left side piping, piping connection for gas should be about ⑥ from this line.

㉖ For left side piping, piping connection for gas should be about ⑥ from this line.

㉗ For left side piping, piping connection for gas should be about ⑥ from this line.

㉘ For left side piping, piping connection for gas should be about ⑥ from this line.

㉙ For left side piping, piping connection for gas should be about ⑥ from this line.

㉚ For left side piping, piping connection for gas should be about ⑥ from this line.

㉛ For left side piping, piping connection for gas should be about ⑥ from this line.

㉜ For left side piping, piping connection for gas should be about ⑥ from this line.

㉝ For left side piping, piping connection for gas should be about ⑥ from this line.

㉞ For left side piping, piping connection for gas should be about ⑥ from this line.

㉟ For left side piping, piping connection for gas should be about ⑥ from this line.

㊱ For left side piping, piping connection for gas should be about ⑥ from this line.

㊲ For left side piping, piping connection for gas should be about ⑥ from this line.

㊳ For left side piping, piping connection for gas should be about ⑥ from this line.

㊴ For left side piping, piping connection for gas should be about ⑥ from this line.

㊵ For left side piping, piping connection for gas should be about ⑥ from this line.

㊶ For left side piping, piping connection for gas should be about ⑥ from this line.

㊷ For left side piping, piping connection for gas should be about ⑥ from this line.

㊸ For left side piping, piping connection for gas should be about ⑥ from this line.

㊹ For left side piping, piping connection for gas should be about ⑥ from this line.

㊺ For left side piping, piping connection for gas should be about ⑥ from this line.

㊻ For left side piping, piping connection for gas should be about ⑥ from this line.

㊼ For left side piping, piping connection for gas should be about ⑥ from this line.

㊽ For left side piping, piping connection for gas should be about ⑥ from this line.

㊾ For left side piping, piping connection for gas should be about ⑥ from this line.

㊿ For left side piping, piping connection for gas should be about ⑥ from this line.

3 TO DRILL A HOLE IN THE WALL AND INSTALL A SLEEVE OF PIPING

- Insert the piping sleeve to the hole.
- Fix the bushing to the sleeve.
- Cut the sleeve until it extrudes about 15 mm from the wall.

CAUTION

When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

④ Finish by sealing the sleeve with putty or caulking compound at the final stage.

1 SELECT THE BEST LOCATION (Refer to "Select the best location" section)

2 INSTALL THE OUTDOOR UNIT

After selecting the best location, start installation to Indoor/Outdoor Unit Installation Diagram.

- Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø10 mm). Make sure unit install in balance level to ensure that water flow out from unit drainage hole.
- When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt, screws or nails.

Model	A	B	C	D
1.OHP	474 mm	87 mm	18.5 mm	261 mm
1.SHP	570 mm	105 mm	18.5 mm	320 mm

3 CONNECT THE PIPING

Connecting The Piping to Indoor

For connection joint of all models Please make flare after inserting (locate at joint portion of tube assembly) onto the copper pipe. (In case of using long piping)

Connect the piping.

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.

Additional Precautions For R32 Models when connecting by flaring at indoor side

Ensure to do re-flaring of pipes before connecting to units to avoid leaking

Seal sufficiently the flare nut (both gas and liquid sides) with neutral cure (Alkoxy type) & ammonia-free silicone sealant and insulation material to avoid the gas leak caused by freezing.

Neutral cure (Alkoxy type) & ammonia-free silicone sealant is only to be applied after pressure testing and cleaning up by following instructions of sealant, only to the outside of the connection. The aim is to prevent moisture from entering the connection joint and possible occurrence of freezing. Curing sealant will take some time. Make sure sealant will not peel off when wrapping the insulation.

Apply neutral cure (Alkoxy type) and ammonia-free silicone sealant along the circumference

Spanner or Wrench Torque wrench

Piping size	Torque
6.35 mm (1/4")	18 N·m (1.8 kg·m)
9.52 mm (3/8")	42 N·m (4.3 kg·m)
12.7 mm (1/2")	55 N·m (5.6 kg·m)
15.88 mm (5/8")	65 N·m (6.6 kg·m)
19.05 mm (3/4")	100 N·m (10.2 kg·m)

Do not overtighten, overtightening may cause gas leakage.

5 CONNECT THE CABLE TO THE OUTDOOR UNIT

- Remove the control board cover from the unit by loosening the screw.
- Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 x 1.5 mm² (1.0 ~ 1.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
- Secure the cable onto the control board with the holder (clammer).
- Attach the control board cover back to the original position with screw.
- For wire stripping and connection requirement, refer to instruction ⑤ of indoor unit.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reason.

Terminals on the outdoor unit

1	2	3
---	---	---

Colour of wires

1	2	3
---	---	---

Terminals on the indoor unit

1	2	3
---	---	---

Indoor and outdoor connection cable

Indoor unit

WARNING

This equipment must be properly earthed.

6 PIPING INSULATION

- Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
- If dry foam or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

4 INDOOR UNIT INSTALLATION

Do not turn over the unit without shock absorber during pull out the piping. It may cause intake grille damage.

Use shock absorber during pull out the piping to protect the intake grille from damage.

1. FOR THE RIGHT REAR PIPING

Step-1 Pull out the Indoor piping

Step-2 Install the Indoor Unit

Step-3 Secure the Indoor Unit

Step-4 Insert the connection cable

2. FOR THE RIGHT AND RIGHT BOTTOM PIPING

Step-1 Pull out the Indoor piping

Step-2 Install the Indoor Unit

Step-3 Insert the connection cable

Step-4 Secure the Indoor Unit

Power supply cord arrangement

Excess length of power supply cord should be arranged behind the chassis at piping keeping area as shown in the diagram without tying up in a bundle. Ensure that the power supply cord is not clamped in between unit's hook (2 position) and installation plate. Ensure that the power supply cord is not stretched between chassis back and installation plate. It may create squeak sound.

Press the area of orange color to release holder

Unit's hook

Installation plate

Power Supply cord

Insert the connection cable

Guide surface

Connection cable

Gas side piping

Liquid side piping

Drain hose

Front panel

Grille door

Screw

4 AIR TIGHTNESS TEST ON THE REFRIGERATING SYSTEM

Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.

There is no extra refrigerant in the outdoor unit for air purging.

Before system is charged with refrigerant and before the refrigerating system is put into operation, below site test procedure and acceptance criteria shall be verified by the certified technicians, and/or the installer.

Be sure to check whole system for gas leakage.

Preparation (Step 1-2)

Evacuation (Step 3-4)

Tightness Test with Inert Gas (Step 5-7)

Pressure drop? (Step 8)

Leak detection and repair (Step 9-12)

Recovery of Test Gas (Step 13)

Evacuation (Step 3-4)

Open 2 and 3 valves (Step 14-18)

Complete

1) Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve. During extremely cold winter, material contraction might happened, try to further tighten the 2-way, 3-way valve to ensure they are fully closed.

2) Attach the gauge manifold set correctly and tightly. Make sure that both valves of the manifold gauge (low pressure and high pressure) is in close position.

3) Connect the center hose of the manifold gauge to a vacuum pump.

4) Turn on the power switch of the vacuum pump, then turn open the low side manifold gauge valve and make sure that the needle in the gauge moves from 0cmHg (0 MPa) to ~76 cmHg (~0.1 MPa) or vacuum until 500 microns is achieved. This process continues for approximately ten minutes.

5) Remove the vacuum pump from the centre hose and connect the center hose to cylinder of any applicable inert gas as test gas.

6) Charge test gas into the system and wait until the pressure within the system to reach min. 1.04MPa (10.4bar).

7) Wait and monitor the pressure reading on the gauges. Check if there is any pressure drop. Waiting time depends on the size of the system.

8) If there is any pressure drop, perform step 9-12. If there is no pressure drop, perform step 13.

9) Use Gas Leak Detector to check for leaks. Must use the detection equipment with a sensitivity of 5 grams per year of test gas or better.

10) Move the probe along the air conditioning system to check for leaks, and mark for repair.

11) Any leak detected and marked shall be repaired.

12) After repair, repeat evacuation steps 3-4 and tightness test steps 5-7. Check the pressure drop as in step 8.

13) If no leak, Recover the test gas. Perform evacuation of steps 3-4. Then proceed to step 14.

14) Disconnect the charging hose from the service port of the 3-way valve.

15) Tighten the service port caps of the 3-way valve at a torque of 18 N·m with a torque wrench.

16) Remove the valve caps of both of the 2-way valve and 3-way valve, using a hexagonal wrench (4 mm).

17) Open both of the valves, allow refrigerant slowly flow into the refrigerant system to prevent refrigerant freezing. Slightly open 2-way valve for 5 seconds then close the valve. Repeat this action for 3 cycles then fully open the valve.

18) Mount back the valve caps onto the 2-way valve and the 3-way valve to complete this process.

Indoor unit

Liquid side

Two-way valve

Outdoor unit

Gas side

Three-way valve

Close

OPEN

Tank Cylinder

Inert gas

Vacuum pump

Notes: Recommended use of any of the following leak detector.

I) Universal Sniffer leak detector

II) Electronic halogen leak detector

III) Ultrasonic Leak Detector

CUTTING AND FLARING THE PIPING

- Please cut using pipe cutter and then remove the burrs.
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- Please make flare after inserting the flare nut onto the copper pipes.

Improper flaring

Point down

Reamer

Handle

Bar

Yoke

Core

Clamp handle

Red arrow mark

1. To cut

2. To remove burrs

3. To flare

When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

3. FOR THE EMBEDDED PIPING

Step-1 Change the drain hose position

Step-2 Bend the embedded piping

Step-3 Pull the connection cable into Indoor Unit

Step-4 Cut and flare the embedded piping

Step-5 Install the Indoor Unit

Step-6 Connect the piping

Step-7 Insulate and finish the piping

Step-8 Secure the Indoor Unit

(This can be used for left rear piping also.)

Change the drain hose position

Rear view for left piping installation

Drain cap

Drain hose

Adjust the piping slightly downwards.

Connection cable

Drain hose

In case of left piping how to insert the connection cable and drain hose.

Drain hose

Cable

Piping

(For the right piping, follow the same procedure)

How to pull the piping and drain hose out, in case of the embedded piping.

Apply putty or caulking material to seal the wall opening.

More than 950 mm

More than 270 mm

Drain hose from main unit

PVC tube (VP-65) for piping and connection cable

PVC tube for drain hose (VP-30)

PVC tube for drain hose (VP-20)

55 mm

Indoor unit

5 CONNECT THE CABLE TO THE INDOOR UNIT

The indoor and outdoor unit connection cable can be connected without removing the front grille.

- Install the indoor unit on the installing holder that mounted on the wall.
- Open the front panel and grille door by loosening the screw.

Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed. 4 x 1.5 mm² (1.0 ~ 1.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.

Bind all the indoor and outdoor Connection cable with tape and route the connection cable via the right side escapement.

Front panel

Grille door

Screw

HOW TO TAKE OUT FRONT GRILLE

Please follow the steps below to take out front grille if necessary such as when installing or servicing.

- Open front panel.
- Remove the 3 mounting screws on the front grille as shown in the illustration below.
- Slide the 3 lock knobs on the upside of front grille to unlock position.
- Pull the front grille towards you to remove the front grille.

Front panel

Front grille

Screw

LOCK

UNLOCK

Lock knob

AUTO SWITCH OPERATION

The below operations will be performed by pressing the "AUTO" switch.

- AUTO OPERATION MODE
- TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)
- REMOTE CONTROLLER RECEIVING SOUND ON/OFF

The Test Run operation will be activated if the AUTO Switch is pressed continuously for more than 5 sec. to below 8 sec. A "pep" sound will occur at the fifth sec., in order to identify the starting of Test Run operation.

The Auto operation will be activated immediately once the Auto Switch is pressed and release within 5 sec..

The ON/OFF of Remote controller receiving sound can be change over by the following steps:

a) Press "AUTO" switch continuously for more than 16 sec. to below 21 sec. A "pep", "pep", "pep", "pep" sound will occur at the sixteenth sec..

b) Press the "AC Reset" button once, "pep" sound will occur indicates that Remote controller receiving sound setting mode is activated.

c) Press "AUTO" switch again. Everytime "AUTO" switch is pressed (within 60 sec. interval), Remote controller receiving sound status will be reversed between ON and OFF. Long "peep" sound indicates that Remote controller receiving sound is ON. Short "pep" sound indicates that Remote controller receiving sound is OFF.

5 Remove the tapes and connect the connection cable between indoor unit and outdoor unit according to the diagram below.

Terminals on the indoor unit

Colour of wires (connection cable)

Terminals on the outdoor unit

1 2 3

1 2 3

④ Connection cable

Terminal Board

Earth Wire longer than others AC wires for safety reason

Control Board

Indoor & outdoor connection cable

Outdoor Unit

WARNING

This equipment must be properly earthed.

WIRE STRIPPING, CONNECTING REQUIREMENT

Wire stripping

No loose strand when inserted

Indoor/outdoor connection terminal board

5 mm or more (gap between wires)

Conductor fully inserted

Conductor over inserted

Conductor not fully inserted

ACCEPT

PROHIBITED

PROHIBITED

WARNING

RISK OF FIRE

JOINING OF WIRES MAY CAUSE OVERHEATING AND FIRE.

Do not joint wires

Use complete wire without joining.

Use approved socket and plug with earth pin.

Wire connection in this area must follow to national wiring rules.

CHECK THE DRAINAGE

- Open front panel and remove air filters. (Drainage checking can be carried out without removing the front grille.)
- Pour a glass of water into the drain tray-styrofoam.
- Ensure that water flows out from drain hose of the indoor unit.

EVALUATION OF THE PERFORMANCE

Poor refrigerant piping could result in product failure.

- In the circumstances listed below, do not reuse any refrigerant piping. Instead, make sure to install a new piping.
 - Heat insulation is not provided for either liquid-side or gas-side piping or both.
 - The existing refrigerant pipe has been left in an open condition.
 - The diameter and thickness of the existing refrigerant piping does not meet the requirement.
 - The piping length and elevation does not meet the requirement.
- Perform proper pump down before reuse piping.
- In the circumstances listed below, clean it thoroughly before reuse.
 - Pump down operation cannot be performed for the existing air-conditioner.
 - The compressor has a failure history.
 - Oil color is darkened. (ASTM 4.0 and above).
 - The existing air-conditioner is gas/oil heat pump type.
- Do not reuse the flare to prevent gas leak. Make sure to install a new flare.
- If there is a welded part on the existing refrigerant piping, conduct a gas leak check on the welded part.
- Replace deteriorated heat insulating material with a new one.
- Heat insulating material is required for both liquid-side and gas-side piping.

Drain tray-styrofoam

Discharge air

Proper Pump Down Method

- Operate air conditioner at cooling mode for 10 ~ 15 minutes.
- After 10 ~ 15 minutes of pre operation, close 2 way valve. After 3 minutes, close 3 way valve.
- Take out air conditioner unit.
- Install New Refrigerant air conditioner.

Most Important Process Purpose: To make the oil & refrigerant mix together. They are in separated condition when air conditioner is stopped.

Mixed refrigerant & oil will be collected into outdoor unit, which is acceptable.

Only very small amount of oil remain inside piping, which is acceptable.

CHECK ITEMS

Is there any gas leakage at flare nut connections?

Has the heat insulation been carried out at flare nut connection?

Is the connection cable being fixed to terminal board firmly?

Is the connection cable being clamped firmly?

Is the drainage ok? (Refer to "Check the drainage" section)

Is the earth wire connection properly done?

Is the indoor unit properly hooked to the installation plate?

Is the power supply voltage complied with rated value?

Is there any abnormal sound?

Is the cooling/heating operation normal?

Is the thermostat operation normal?

Is the remote control's LCD operation normal?